

JBC
www.jbctools.com



Feel the quality, be exclusive
Cartridge Guide

**This cartridge guide contains all original JBC
soldering tips that are available through our central
stock in Rodgau Germany.**

**Normally leadtime on stocked items are 2-3 days
from purchase date.**

If out of stock expect 2 weeks leadtime.

Contact our sales staff for further questions.

www.smarttec.dk

Index

| | |
|---------------------------------------|----|
| High Technology for quality soldering | 4 |
| Bigger is better | 6 |
| Factors limiting life of tips | 7 |
| Cleaning systems | 8 |
| C105 Cartridges range | 12 |
| C120 Cartridges range | 16 |
| C130 Cartridges range | 18 |
| C210 Cartridges range | 20 |
| C245 Cartridges range | 24 |
| C250 Cartridges range | 44 |
| C420 Cartridges range | 47 |
| C470 Cartridges range | 50 |
| C360 Tips range | 58 |
| C560 Tips range | 60 |



A global organization at your service

JBC is a global company with a distributor network spanning 5 continents that guarantees a solid commercial organization with quick and efficient service.

The power of experience

More than 85 years of experience have placed JBC at the technological forefront of tools for soldering and rework operations in electronics. Innovation, efficiency and reliability are the key features of a wide range of products which have been designed to satisfy the most demanding requirements of professionals.

High technology, superior quality

Product perfection is one of the main objectives of JBC's improvement and development program. The R&D department has created the most innovative soldering technologies, which JBC is proud to present in this catalogue.

CE
ESD safe

All JBC products comply with CE standards and ESD recommendations.




JBC Soldering SL. reserves the right to update, modify or delete any information without previous notice.

High Technology for quality soldering

The JBC Exclusive Heating System


JBC's stations work with the JBC Exclusive Heating System which recovers tip temperature extremely quickly. This increases work efficiency and allows the user to work with lower temperatures.



Enhanced Temperature Efficiency → Increase Productivity + Better Quality


Efficient Temperature Control

Comparative process of 3 solder joints




The Intelligent Heat Management

The JBC equipment also incorporates the **Sleep & Hibernation** modes to help extend tip life by further reducing the temperature when the tool is not in use. As a result, tip life increases by 5.




Tip life increases exponentially by using lower temperatures as shown. Using the **Sleep** mode the temperature is further reduced, which extends tip life by 5.



Cartridges with extended tip life

The essential part of the soldering iron is the tip so JBC has over 400 models of cartridges of different sizes and shapes to choose from depending on each application. JBC has developed the most advanced technology based on the following principles:



- **Excellent Heat Transfer**
The compact element reduces thermal barriers.
- **Instantaneous Heating Up**
A fully integrated thermal sensor in the heater ensures quick temperature recovery.
- **Great Durability**
The intelligent algorithm control program extends tip life.

When you start working do not forget:

Bigger is better


As you know, **the bigger the solder tip, the better the thermal transfer.**
So remember to select **the biggest tip possible** for your application.

Over 400 tips of different sizes, shapes and power




The JBC range includes models from 00,1 mm for precision work to the Ø15 mm for high power requirement applications.

Geometry
Slimness vs Efficiency




A high thermal efficient tip makes your job up to **40% faster** than a tip with a slimmer geometry.

Increase the contact surface Tip-Application



The bigger the contact surface the tip has with application, the higher the **thermal transfer**.

Largest mass possible



The more mass the tip has, the more heat accumulated and the **lower the temperature drop**.

Maintain tip surface clean and tinned



Remember that rusty and dirty surfaces reduce **heat transfer** to the solder joint.
(See JBC's cleaning methods on pages 8-9).

Factors limiting life of tips


► **Working temperature**
The higher the temperature, the higher the oxidation and the corrosion. Work at the lowest possible temperature. Use thermal efficient tools and keep tips clean of oxidation.

► **Flux and solder alloy**
Too much active Flux can cause corrosion. IPC recommends: ROL, REL and ORL. The internal flux from small Ø solder reels might not be enough. Provide external Flux if necessary.

► **Correct soldering techniques**
Too much pressure on the surface to solder can cause tip or plate breakage. Do not use as a pointed object or a screwdriver. Choose the biggest possible tip for each application to work at the lowest possible temperature.


► **Iron plating thickness**
The wearing down of the plate shortens its life (hollowed-out). Do not use mechanical or chemical means to clean the tip. Use the cleaning methods provided by the manufacturer. Do not apply too much pressure.

► **Oxidization**
Iron oxide does not wet nor transfer temperature well (dewetting). The higher the temperature, the greater the risk of oxidation. Keep tips always tinned while not in use. Use flux on your solder joints. Take advantage of SLEEP & HIBERNATION functions.



Remember

- Always work at the **LOWEST POSSIBLE TEMPERATURE**.
- Use **THERMAL EFFICIENT TOOLS**.
- Choose the **BIGGEST** tip possible.
- IPC recommends **FLUX ROL, REL and ORL**.
- Protect the tip with a **TIN COATING** when not in use.
- Use the **SLEEP & HIBERNATION** functions.
- **DO NOT** apply too much pressure to the tip
- Use the **CLEANING METHODS** recommended by the manufacturer.
- Only use re-tinners when absolutely necessary.



Cleaning systems

JBC offers effective, practical and affordable methods to prevent splashing and extend a tip's life:

Clean the tip in a fraction of a second



With automatic cleaners you get **optimal and uniform cleaning** in a very short time.

Easy to empty



The solder collector tray can be **easily emptied and re-used** with no wear and tear.

Keep your work area clean



The splashguard helps **keep the bench always clean** and free of solder particles.

Automatic Junior Tip Cleaner

Ref. [CLMS](#)

Save space

You can easily fit the tip cleaner into your work area thanks to its reduced size.

Two modes of operation

The motorized brushes start by pressing the button or by selecting the continuous mode.



Automatic Universal Tip Cleaner

Ref. [CLMU-A](#)

Continuous or Sensor mode

This Cleaner is excellent for cleaning tips with different shapes and sizes. You can easily switch between sensor and continuous mode by pressing the top buttons.



Brushes for CLMU



Brushes for CLMS
Ref. [CLMS-A8](#)



Ref. [CLMU-A8](#)

Ref. [CLMU-P1](#)
Non metal brushes

Ref. [CLMU-P7](#)
Non metal brushes

ESD Tip Cleaner

Ref. [CL8499](#)

Brass wool

Ref. [CL6210](#)

Very effective cleaning method. Leaves a small layer of solder on the tip preventing oxidation between cleaning.



Sponge

Ref. [CL0354](#)

This is the softest method. Be sure to have the sponge always clean and wet, not soaked, with de-ionated water.



Our cartridge range
is steadily growing as we are determined
to respond to our client's specific needs
cooperating closely with them
to create the right solution











C105 Cartridge range for NP105 & NT105 Nano tools

| | Ref. | Description | Image & dimensions | Suggested components | Connectables |
|--|----------|----------------------------|--------------------|--|---|
| | C105-126 | Cartridge Conical Ø 0,1 | | Package 01005 Very fine pitch 0,4mm QFP, IC, | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
| | C105-101 | Cartridge Conical Ø 0,1 | | Package 01005 Very fine pitch 0,4mm QFP, IC, | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
| | C105-103 | Cartridge Conical Ø 0,3 S1 | | Package 0201, 0402 Fine pitch 0,65mm QFP, IC, .. | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
| | C105-106 | Cartridge Conical Ø 0,5 | | Package 0603 QFP, IC, .. | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
| | C105-107 | Cartridge Conical Ø 0,8 | | General use | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
| | C105-124 | Cartridge Bent Ø 0,1 S1 | | Package 01005 Very fine pitch 0,4mm QFP, IC, .. | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
| | C105-118 | Cartridge Bent Ø 0,1 | | Package 01005 Very fine pitch 0,4mm QFP, IC, .. | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |







C105 Cartridges for NP105 & NT105 Nano tools

| | Ref. | Description | Image & dimensions | Suggested components | Connectables |
|--|----------|-----------------------------|--------------------|---|---|
| | C105-105 | Cartridge Bent Ø 0,3 | | Package 0201, 0402 Fine pitch 0,65mm QFP, IC, .. | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
| | C105-110 | Cartridge Bent Ø 0,5 | | Package 0603 QFP, IC, | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
| | C105-116 | Cartridge Chisel 0,2 x 0,1 | | Package 01005, 0201 Very fine pitch 0,4mm QFP, IC, .. | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
| | C105-117 | Cartridge Chisel 0,4 x 0,2 | | Package 0402 Very fine pitch 0,65mm QFP, IC, .. | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
| | C105-108 | Cartridge Chisel 0,6 x 0,3 | | Package 0603 PLCC, SO, SOT,.. | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
| | C105-125 | Cartridge Chisel 1 x 0,2 | | Package 0805 Difficult to reach | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
| | C105-113 | Cartridge Chisel 1 x 0,3 | | Package 0805 Through hole | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
| | C105-213 | Cartridge Chisel 1 x 0,3 S1 | | Package 0805 Through hole | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |

C105 Cartridges for NP105 & NT105 Nano tools

| | Ref. | Description | Image & dimensions | Suggested components | Connectables |
|---|----------|---------------------------------------|--|---|---|
|  | C105-221 | Cartridge Chisel 1,3 x 0,3 |  5 mm $(0,197\text{ in})$ | Package 0805 Through hole | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
|  | C105-222 | Cartridge Chisel 1,6 x 0,3 |  5 mm $(0,197\text{ in})$ | Package 0805 Through hole | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
|  | C105-114 | Cartridge Chisel 1,8 x 0,5 |  5 mm $(0,197\text{ in})$ | Package 1206, 1210 Through hole | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
|  | C105-214 | Cartridge Chisel 1,8 x 0,5 S1 |  5 mm $(0,197\text{ in})$ | Package 1206, 1210 Through hole | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
|  | C105-223 | Cartridge Chisel 2,4 x 0,6 |  5 mm $(0,197\text{ in})$ | Package 0805 Through hole | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
|  | C105-115 | Cartridge Cutter Stainless Steel 1 |  6 mm $(0,236\text{ in})$ | Stainless Steel Remove underfill encapsulants | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
|  | C105-109 | Cartridge Bevel \varnothing 0,6 |  5 mm $(0,197\text{ in})$ | Drag soldering SMD Through hole | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
|  | C105-127 | Cartridge Bevel \varnothing 1 |  $4,5\text{ mm}$ $(0,177\text{ in})$ | Drag soldering SMD Through hole | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |

C105 Cartridges for NP105 & NT105 Nano tools

| | Ref. | Description | Image & dimensions | Suggested components | Connectables |
|---|----------|------------------------------------|---|---|---|
|  | C105-128 | Cartridge Spoon \varnothing 1 |  $4,5\text{ mm}$ $(0,177\text{ in})$ | Drag soldering SMD Through hole | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
|  | C105-120 | Cartridge Knife 1 x 0,2 |  $0,2\text{ mm}$ $(0,008\text{ in})$ | Drag soldering SMD Package 0805 Through hole | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
|  | C105-112 | Cartridge Knife 2,5 x 0,3 |  $0,3\text{ mm}$ $(0,012\text{ in})$ | Drag soldering SMD SO, SOT,.. Package 1210, 1812, 2010, 2512 | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
|  | C105-212 | Cartridge Knife 2,5 x 0,3 S1 |  $0,3\text{ mm}$ $(0,012\text{ in})$ | Drag soldering SMD SO, SOT,.. Package 1210, 1812, 2010, 2512 | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
|  | C105-111 | Cartridge Knife 3,5 x 0,7 |  $0,7\text{ mm}$ $(0,028\text{ in})$ | Package 1210, 1812 SO, SOT,.. | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |
|  | C105-211 | Cartridge Knife 3,5 x 0,7 |  $0,7\text{ mm}$ $(0,028\text{ in})$ | Package 1210, 1812 SO, SOT,.. | Station: NASE, NANE Tools: NP105-A NP105-B NT105-A |



C120 Cartridge range for PA120 Micro Tweezers

| | Ref. | Description | Image & dimensions | Suggested components | Connectables |
|--|-----------------|------------------------------|--------------------|---|--|
| | C120-001 | Cartridge Dual in Line Ø 0,2 | | Package 0201, 0402 | Control Units: CP, DI, DDE, DME Tool: PA120-A |
| | C120-002 | Cartridge Chip Ø 0,2 | | Package 0201, 0402 | Control Units: CP, DI, DDE, DME Tool: PA120-A |
| | C120-902 | Cartridge Chip Ø 0,3 | | Package 0201, 0402 Fine pitch 0.65mm QFP, IC, .. | Control Units: CP, DI, DDE, DME Tool: PA120-A |
| | C120-006 | Cartridge Chip Ø 0,5 | | Package 0603 QFP, IC, .. | Control Units: CP, DI, DDE, DME Tool: PA120-A |
| | C120-004 | Cartridge Chip Ø 0,7 S1 | | SMD capacitors QFP, IC, .. Through hole | Control Units: CP, DI, DDE, DME Tool: PA120-A |
| | C120-012 | Cartridge Chip Ø 0,7 S2 | | SMD capacitors QFP, IC, .. Through hole | Control Units: CP, DI, DDE, DME Tool: PA120-A |
| | C120-011 | Cartridge Chip 0,6 | | Package 0603 | Control Units: CP, DI, DDE, DME Tool: PA120-A |

C120 Cartridges for PA120 Micro Tweezers

| | Ref. | Description | Image & dimensions | Suggested components | Connectables |
|--|-----------------|----------------------------------|--------------------|----------------------------------|--|
| | C120-003 | Cartridge Dual in Line 3 | | Package 1210, 1812 SO, SOT,.. | Control Units: CP, DI, DDE, DME Tool: PA120-A |
| | C120-005 | Cartridge Dual in Line 5 | | SO, SOT,.. | Control Units: CP, DI, DDE, DME Tool: PA120-A |
| | C120-007 | Cartridge Dual in Line 3,5 Right | | Package 1210, 1812 SO, SOT,.. | Control Units: CP, DI, DDE, DME Tool: PA120-A |
| | C120-008 | Cartridge Dual in Line 3,5 Left | | Package 1210, 1812 SO, SOT,.. | Control Units: CP, DI, DDE, DME Tool: PA120-A |
| | C120-009 | Cartridge Dual in Line 6 Right | | SO, SOT,.. | Control Units: CP, DI, DDE, DME Tool: PA120-A |
| | C120-010 | Cartridge Dual in Line 6 Left | | SO, SOT,.. | Control Units: CP, DI, DDE, DME Tool: PA120-A |



C130 Cartridge range for AP130 Solder Feed Iron







| | Ref. | Description | Image & dimensions | Suggested components | Connectables |
|--|----------|----------------------|--------------------|-----------------------------|--|
| | C130-401 | Cartridge Bent Ø 0,6 | | Through hole General use | Control Units: CF, DI, DDE, DME Tool: AP130-A |
| | C130-402 | Cartridge Bent Ø 0,8 | | Through hole General use | Control Units: CF, DI, DDE, DME Tool: AP130-A |
| | C130-403 | Cartridge Bent Ø 1 | | Through hole General use | Control Units: CF, DI, DDE, DME Tool: AP130-A |
| | C130-409 | Cartridge Bent Ø 1,7 | | Through hole General use | Control Units: CF, DI, DDE, DME Tool: AP130-A |
| | C130-410 | Cartridge Bent Ø 2,2 | | Through hole General use | Control Units: CF, DI, DDE, DME Tool: AP130-A |
| | C130-416 | Cartridge Bent Ø 3 | | Through hole General use | Control Units: CF, DI, DDE, DME Tool: AP130-A |
| | C130-417 | Cartridge Bent Ø 4 | | Through hole General use | Control Units: CF, DI, DDE, DME Tool: AP130-A |

C130 Cartridges for AP130 Solder Feed Iron






| | Ref. | Description | Image & dimensions | Suggested components | Connectables |
|--|----------|--------------------------|--------------------|-----------------------------|--|
| | C130-404 | Cartridge Bent 1,2 x 0,7 | | Through hole General use | Control Units: CF, DI, DDE, DME Tool: AP130-A |
| | C130-405 | Cartridge Bent 1,8 x 0,8 | | Through hole General use | Control Units: CF, DI, DDE, DME Tool: AP130-A |
| | C130-406 | Cartridge Bent 2,2 x 1 | | Through hole General use | Control Units: CF, DI, DDE, DME Tool: AP130-A |
| | C130-418 | Cartridge Bent 3,2 x 1,5 | | Through hole General use | Control Units: CF, DI, DDE, DME Tool: AP130-A |
| | C130-419 | Cartridge Bent 4,8 x 1,5 | | Through hole General use | Control Units: CF, DI, DDE, DME Tool: AP130-A |











C210 Cartridge range for T210 Precision Purpose Handles

| | Ref. | Description | Image & dimensions | Suggested components | Connectables |
|--|----------|----------------------------|--|--|--|
| | C210-020 | Cartridge Conical Ø 0,1 |   | Package 01005, 0201 Very fine pitch 0,4mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T210 range |
| | C210-009 | Cartridge Conical Ø 0,2 |   | Package 01005, 0201 Very fine pitch 0,4mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T210 range |
| | C210-016 | Cartridge Conical Ø 0,3 S1 |   | Package 0201, 0402 Fine pitch 0,65mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T210 range |
| | C210-001 | Cartridge Conical Ø 0,3 S2 |   | Package 0201, 0402 Fine pitch 0,65mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T210 range |
| | C210-013 | Cartridge Conical Ø 0,5 |   | Package 0603 QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T210 range |
| | C210-003 | Cartridge Conical Ø 0,6 |   | General use | Control Units: CD, DI, DDE, DME Tools: T210 range |
| | C210-005 | Cartridge Conical Ø 1 |  | General use | Control Units: CD, DI, DDE, DME Tools: T210 range |








C210 Cartridges for T210 Precision Purpose Handles

| | Ref. | Description | Image & dimensions | Suggested components | Connectables |
|--|----------|-----------------------|--|---|--|
| | C210-002 | Cartridge Bent Ø 0,2 |   | Package 0201, 0402 | Control Units: CD, DI, DDE, DME Tools: T210 range |
| | C210-010 | Cartridge Bent Ø 0,3 |   | Package 0201, 0402 Fine pitch 0,65mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T210 range |
| | C210-014 | Cartridge Bent Ø 0,5 |   | Package 0603 QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T210 range |
| | C210-004 | Cartridge Bent Ø 0,7 |   | General use | Control Units: CD, DI, DDE, DME Tools: T210 range |
| | C210-006 | Cartridge Bevel Ø 1 |   | Drag Soldering General use | Control Units: CD, DI, DDE, DME Tools: T210 range |
| | C210-027 | Cartridge Bevel Ø 1,5 |   | Drag Soldering General use | Control Units: CD, DI, DDE, DME Tools: T210 range |
| | C210-031 | Cartridge Bevel Ø 2 |   | Drag Soldering General use | Control Units: CD, DI, DDE, DME Tools: T210 range |
| | C210-028 | Cartridge Spoon Ø 1 |  | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T210 range |

C210 Cartridges for T210 Precision Purpose Handles

| | Ref. | Description | Image & dimensions | Suggested components | Connectables |
|---|----------|----------------------------|---|---|--|
|  | C210-029 | Cartridge Spoon Ø 1,5 |  mm (in) | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T210 range |
|  | C210-030 | Cartridge Spoon Ø 2 |  mm (in) | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T210 range |
|  | C210-019 | Cartridge Chisel 0,2 x 0,1 |  mm (in) | Package 01005, 0201 Very fine pitch 0,4mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T210 range |
|  | C210-023 | Cartridge Chisel 0,4 x 0,2 |  mm (in) | Package 0402 Very fine pitch 0,65mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T210 range |
|  | C210-021 | Cartridge Chisel 0,6 x 0,3 |  mm (in) | Package 0603 | Control Units: CD, DI, DDE, DME Tools: T210 range |
|  | C210-024 | Cartridge Chisel 0,8 x 0,3 |  mm (in) | Package 0805 Through hole | Control Units: CD, DI, DDE, DME Tools: T210 range |
|  | C210-022 | Cartridge Chisel 1,3 x 0,4 |  mm (in) | Package 0805 Through hole | Control Units: CD, DI, DDE, DME Tools: T210 range |
|  | C210-008 | Cartridge Chisel 1,3 x 0,6 |  mm (in) | Package 0805 Through hole | Control Units: CD, DI, DDE, DME Tools: T210 range |

C210 Cartridges for T210 Precision Purpose Handles

| | Ref. | Description | Image & dimensions | Suggested components | Connectables |
|---|----------|-------------------------------|--|---|--|
|  | C210-007 | Cartridge Chisel 2,3 x 0,7 |  mm (in) | Package 0805 Through hole | Control Units: CD, DI, DDE, DME Tools: T210 range |
|  | C210-017 | Cartridge Pin Ø 0,7 |  mm (in) | Through hole | Control Units: CD, DI, DDE, DME Tools: T210 range |
|  | C210-015 | Cartridge Pin/Connector Ø 0,8 |  VIEW A VIEW B mm (in) | Through hole Coaxial connector | Control Units: CD, DI, DDE, DME Tools: T210 range |
|  | C210-025 | Cartridge Pin/Connector Ø 1,1 |  mm (in) | Through hole Coaxial connector | Control Units: CD, DI, DDE, DME Tools: T210 range |
|  | C210-012 | Cartridge Pin/Wire Ø 1 |  mm (in) | Cables Connectors | Control Units: CD, DI, DDE, DME Tools: T210 range |
|  | C210-018 | Cartridge Knife 3,4 x 0,3 |  mm (in) | Drag soldering SMD SO, SOT,.. Package 1210, 1812, 2010, 2512 | Control Units: CD, DI, DDE, DME Tools: T210 range |












C245 Cartridge range for T245 Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|----------------------------|-------|--|--|
| | C245-030 | Cartridge Conical Ø 0,3 | | Package 0201, 0402 Fine pitch 0,65mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-032 | Cartridge Conical Ø 0,4 | | Package 0201, 0402 Fine pitch 0,65mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-036 | Cartridge Conical Ø 0,5 S1 | | Package 0603 QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-930 | Cartridge Conical Ø 0,5 S2 | | Package 0603 QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-001 | Cartridge Conical Ø 0,6 | | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-201 | Cartridge Conical Ø 0,6 L | | Package 0603 QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-937 | Cartridge Conical Ø 0,6 HT | | Package 0603 QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T245 range |









C245 Cartridges for T245 Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|--------------------------|-------|---|--|
| | C245-957 | Cartridge Conical Ø 0,8 | | Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-903 | Cartridge Conical Ø 1 S1 | | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-803 | Cartridge Conical Ø 1 L | | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-041 | Cartridge Conical Ø 1 S2 | | General use Tip with an extra tinned surface | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-403 | Cartridge Conical Ø 1 HT | | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-943 | Cartridge Conical Ø 1,7 | | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-933 | Cartridge Conical Ø 2,2 | | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-107 | Cartridge Conical Ø 3 HT | | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |









C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|---------------------------|---|--|--|
|  | C245-034 | Cartridge Bent Ø 0,4 S1 |  | Package 0201, 0402 Fine pitch 0,65mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-234 | Cartridge Bent Ø 0,4 S1 L |  | Package 0201, 0402 Fine pitch 0,65mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-029 | Cartridge Bent Ø 0,4 S2 |  | Package 0201, 0402 Fine pitch 0,65mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-126 | Cartridge Bent Ø 0,4 S3 |  | Package 0201, 0402 Fine pitch 0,65mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-786 | Cartridge Bent Ø 0,4 S4 |  | Package 0201, 0402 Fine pitch 0,65mm QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-929 | Cartridge Bent Ø 0,6 |  | Package 0603 QFP, IC, .. | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-935 | Cartridge Bent Ø 0,8 |  | Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-904 | Cartridge Bent Ø 1 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |









C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|------------------------------|---|------------------------------|--|
|  | C245-804 | Cartridge Bent Ø 1 L |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-259 | Cartridge Bent Ø 1,5 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-260 | Cartridge Bent Ø 2 HT |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-627 | Cartridge Bent Ø 3 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-628 | Cartridge Bent Ø 4 HT |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-731 | Cartridge Chisel 0,6 x 0,3 |  | Package 0603 | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-773 | Cartridge Chisel 0,8 x 0,3 |  | Package 0805 Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-673 | Cartridge Chisel 0,8 x 0,3 L |  | Package 0805 Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |








C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|--|-----------------|----------------------------------|---|------------------------------|--|
| | C245-742 | Cartridge Chisel 0,8 x 0,6 HT |  | Package 0805 Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-774 | Cartridge Chisel 1,2 x 0,3 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-906 | Cartridge Chisel 1,2 x 0,7 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-806 | Cartridge Chisel 1,2 x 0,7 L |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-406 | Cartridge Chisel 1,2 x 0,7 HT |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-768 | Cartridge Chisel 1,5 x 0,3 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-944 | Cartridge Chisel 1,8 x 0,8 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-844 | Cartridge Chisel 1,8 x 0,8 L |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |









C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|--|-----------------|----------------------------------|---|----------------------|--|
| | C245-907 | Cartridge Chisel 2,2 x 1 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-807 | Cartridge Chisel 2,2 x 1 L |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-407 | Cartridge Chisel 2,2 x 1 HT |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-759 | Cartridge Chisel 2,4 x 0,5 HT |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-770 | Cartridge Chisel 2,4 x 0,3 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-741 | Cartridge Chisel 2,4 x 0,6 HT |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-729 | Cartridge Chisel 2,7 x 1 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-061 | Cartridge Chisel 3 x 1 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |









C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|----------------------------------|---|----------------------|--|
| | C245-261 | Cartridge Chisel 3 x 1 L |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-911 | Cartridge Chisel 3,2 x 1,2 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-811 | Cartridge Chisel 3,2 x 1,2 L |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-775 | Cartridge Chisel 3,2 x 1,2 S1 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-755 | Cartridge Chisel 4 x 0,8 HT |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-756 | Cartridge Chisel 4,8 x 1 HT |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-908 | Cartridge Chisel 4,8 x 1,5 HT S1 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-808 | Cartridge Chisel 4,8 x 1,5 HT L |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |









C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|----------------------------------|---|----------------------|--|
| | C245-708 | Cartridge Chisel 4,8 x 1,5 HT S2 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-069 | Cartridge Chisel 5 x 1,7 HT |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-966 | Cartridge Chisel 6,6 x 1,8 HT |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-962 | Cartridge Bent 1,2 x 0,7 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-862 | Cartridge Bent 1,2 x 0,7 L |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-963 | Cartridge Bent 1,8 x 0,8 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-863 | Cartridge Bent 1,8 x 0,8 L |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-946 | Cartridge Bent 2,2 x 1,0 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |









C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|-------------------------------|---|---|--|
|  | C245-846 | Cartridge Bent 2,2 x 1 L |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-732 | Cartridge Bent 3,2 x 1,5 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-761 | Cartridge Bent 3,0 x 1 |  | General use | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-748 | Cartridge Bent Bevel Ø 0,6 S1 |  | Package 0603 Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-749 | Cartridge Bent Bevel Ø 0,6 S2 |  | Package 0603 Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-747 | Cartridge Bevel Ø 0,6 |  | Package 0603 Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-710 | Cartridge Bevel Ø 1,2 |  | Drag soldering Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-064 | Cartridge Bevel Ø 1,3 |  | Drag soldering Through hole Hoof tip with reduced tinned surface, ideal for tuch up | Control Units: CD, DI, DDE, DME Tools: T245 range |












C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|--------------------------|---|---|--|
|  | C245-905 | Cartridge Bevel Ø 1,5 |  | Drag soldering Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-405 | Cartridge Bevel Ø 1,5 HT |  | Drag soldering Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-102 | Cartridge Bevel Ø 2 |  | Drag soldering Through hole Hoof tip with reduced tinned surface, ideal for tuch up | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-945 | Cartridge Bevel Ø 2,2 |  | Drag soldering Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-845 | Cartridge Bevel Ø 2,2 L |  | Drag soldering Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-784 | Cartridge Bevel Ø 2,8 |  | Drag soldering Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-793 | Cartridge Bevel Ø 2,8 |  | Drag soldering Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-912 | Cartridge Bevel Ø 3 |  | Drag soldering Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |












C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|----------------------------|---|--------------------------------|--|
|  | C245-812 | Cartridge Bevel Ø 3 L |   | Drag soldering Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-056 | Cartridge Bevel Ø 3,5 HT |   | Drag soldering Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-256 | Cartridge Bevel Ø 3,5 HT L |   | Drag soldering Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-951 | Cartridge Bevel Ø 3,8 HT |   | Drag soldering Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-766 | Cartridge Bevel Ø 5 |   | Wide area | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-301 | Cartridge Bevel Ø 8,8 |   | Wide area | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-965 | Cartridge Spoon Ø 1,9 |   | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-067 | Cartridge Spoon Ø 2,3 |   | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |









C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|--------------------------------|---|----------------------------------|--|
|  | C245-931 | Cartridge Spoon Ø 2,7 |   | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-938 | Cartridge Spoon Ø 3,8 |   | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-790 | Cartridge Pin/Connector Ø 0,8 |   | Through hole Cable sold/desol | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-785 | Cartridge Pin/Connector Ø 1,5 |   | Through hole Cable sold/desol | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-763 | Cartridge Pin/Connector Ø 2,5 |   | Through hole Cable sold/desol | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-760 | Cartridge Pin/Connector Ø 3,5 |   | Through hole Cable sold/desol | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-762 | Cartridge Pin/Connector R. 4,5 |   | Cable sold/desol | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-789 | Cartridge Knife 3,5 x 0,3 |   | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |








C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|------------------------------|---|--|--|
|  | C245-939 | Cartridge Knife 6.0 x 0.4 |  | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-765 | Cartridge Knife 6.0 x 0.4 S1 |  | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-955 | Cartridge Knife 13.0 x 0.5 |  | Drag Soldering Conector desoldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-914 | Cartridge Blade 10 S1 |  | Pad cleaning Conector desoldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-752 | Cartridge Blade 15 |  | Pad cleaning Conector desoldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-913 | Cartridge Blade 21 |  | Pad cleaning Conector desoldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-949 | Cartridge Blade 32 |  | Pad cleaning Conector desoldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-776 | Cartridge Blade 37 |  | Pad cleaning Conector desoldering | Control Units: CD, DI, DDE, DME Tools: T245 range |











C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|-----------------------|---|--------------------------------------|--|
|  | C245-792 | Cartridge Blade 40 |  | Pad cleaning Conector desoldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-757 | Cartridge Chip 1.25 |  | SMD resistors SMD capacitors | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-016 | Cartridge Chip 1.9 |  | SMD resistors SMD capacitors | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-758 | Cartridge Chip 2 |  | SMD resistors SMD capacitors | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-017 | Cartridge Chip 2.2 S1 |  | SMD resistors SMD capacitors | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-150 | Cartridge Chip 2.2 S2 |  | SMD resistors SMD capacitors | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-018 | Cartridge Chip 3.4 |  | SMD resistors SMD capacitors | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-019 | Cartridge Chip 4.5 |  | SMD resistors SMD capacitors | Control Units: CD, DI, DDE, DME Tools: T245 range |











C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|--------------------------|---|----------------------|--|
|  | C245-754 | Cartridge Drag 0,75 |  | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-654 | Cartridge Drag 0,75 L |  | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-751 | Cartridge Drag 1,25 |  | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-651 | Cartridge Drag 1,25 L |  | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-667 | Cartridge Drag 1,25 S1 L |  | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-669 | Cartridge Drag 1,25 S2 L |  | Drag soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-220 | Cartridge Tunnel 5,4 x 6 |  | Dual in Line IC | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-250 | Cartridge Tunnel 5,4 x 8 |  | Dual in Line IC | Control Units: CD, DI, DDE, DME Tools: T245 range |










C245 Cartridges for **T245** Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|----------------------------|---|----------------------|--|
|  | C245-221 | Cartridge Tunnel 5,4 x 10 |  | Dual in Line IC | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-303 | Cartridge Tunnel 6,5 x 6 |  | Dual in Line IC | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-222 | Cartridge Tunnel 7,1 x 13 |  | Dual in Line IC | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-306 | Cartridge Tunnel 9,6 x 10 |  | Dual in Line IC | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-305 | Cartridge Tunnel 9,6 x 12 |  | Dual in Line IC | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-304 | Cartridge Tunnel 9,6 x 15 |  | Dual in Line, IC | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-215 | Cartridge Tunnel 9,6 x 18 |  | Dual in Line IC | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-226 | Cartridge Tunnel 15,2 x 29 |  | Dual in Line IC | Control Units: CD, DI, DDE, DME Tools: T245 range |

C245 Cartridges for T245 Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|------------------------------|---|--|--|
|  | C245-223 | Cartridge QFP 8,5 x 8,5 |  | QFP | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-224 | Cartridge QFP 12 x 12 |  | QFP | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-228 | Cartridge QFP 12,4 x 15 |  | QFP | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-315 | Cartridge QFP 15 x 15 |  | QFP | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-227 | Cartridge QFP 17,5 x 17,5 |  | QFP | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-248 | Cartridge Socket 11,9 x 14,5 |  | PLCC sockets | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-247 | Cartridge Socket 17 x 17 |  | PLCC sockets | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-053 | Cartridge Rivet Ø 3,8 |  | Chrome finisg, design for plastic rivets | Control Units: CD, DI, DDE, DME Tools: T245 range |

C245 Cartridges for T245 Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|---------------------------------|---|---|--|
|  | C245-052 | Cartridge Rivet Ø 4,9 |  | Chrome finisg, design for plastic rivets | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-054 | Cartridge Rivet Ø 6,5 |  | Chrome finisg, design for plastic rivets | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-312 | Cartridge for Plastics Ø 3,2 |  | Plastics | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-313 | Cartridge for Plastics Ø 4,1 |  | Plastics | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-123 | Cartridge for Plastics 4 x 4 |  | Plastics | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-124 | Cartridge for Plastics 4,25 x 2 |  | Plastics | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-109 | Cartridge Cutter 4,3 x 0,1 |  | Plastics Remove underfill encapsulants | Control Units: CD, DI, DDE, DME Tools: T245 range |
|  | C245-138 | Cartridge Cutter 12 |  | Plastic Rubber cutter | Control Units: CD, DI, DDE, DME Tools: T245 range |

C245 Cartridges for T245 Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|----------------------------------|-------|---|--|
| | C245-121 | Cartridge Cutter 13 | | Plastic Rubber cutter | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-311 | Cartridge for Plastics 20 x 6 | | Plastics | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-119 | Cartridge Conical Teflon Ø 1 | | Plastics | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-116 | Cartridge Pin/Connector R. 1 | | Through hole Coaxial connector | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-122 | Cartridge Pin/Connect. 1,5 x 0,5 | | Cylinder parts | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-764 | Cartridge Fine Pitch Ø 0,5 | | Package 0603 QFP, IC, .. Fine pitch | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-771 | Cartridge Bent 1 x 0,1 | | Cable soldering to connector Fine pitch | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-117 | Cartridge Flat Ø 1,45 | | Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |

C245 Cartridges for T245 Handles

| | Ref. | Description | Image | Suggested components | Connectables |
|--|-----------|-------------------------------|-------|--|--|
| | C245-118 | Cartridge Pin/Wire 0,4 | | Through hole Wire tinning | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-730 | Cartridge Blade 10 S2 | | Pad cleaning Conector desoldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-268 | Cartridge Pin/Wire 1,5 | | Through hole | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-136 | Cartridge Micro Stick Switch | | Micro Stick desoldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-772 | Cartridge Nickel 1,4 x 0,7 S1 | | HMP soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-009 | Cartridge S-Lead 4,5 x 1,8 | | Drag Soldering | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-010 | Cartridge J-Lead 4,5 x 1,8 | | Drag soldering J-lead | Control Units: CD, DI, DDE, DME Tools: T245 range |
| | C245-SP01 | Solder Pot Cartridge 15 x 18 | | Tinning wires Desoldering Through Hole Multipin components | Control Units: CD, DI, DDE, DME Tools: T245 range |





C250 Cartridge range for AL250 Auto-Feed & AP250 Solder Feed Irons

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|--------------------------|-------|--|---|
| | C250-420 | Cartridge Bent Ø 0,4 | | Package 0201, 0402 Fine pitch 0,65mm QFP, IC, .. | Stations: AL, CA Tools: AL250-B AP250 |
| | C250-401 | Cartridge Bent Ø 0,6 | | Package 0603 QFP, IC, .. | Stations: AL, CA Tools: AL250-B AP250 |
| | C250-402 | Cartridge Bent Ø 0,8 | | General use | Stations: AL, CA Tools: AL250-B AP250 |
| | C250-403 | Cartridge Bent Ø 1 | | General use | Stations: AL, CA Tools: AL250-B, AP250 |
| | C250-409 | Cartridge Bent Ø 1,7 | | General use | Stations: AL, CA Tools: AL250-B AP250 |
| | C250-410 | Cartridge Bent Ø 2,2 | | General use | Stations: AL, CA Tools: AL250-B AP250 |
| | C250-404 | Cartridge Bent 1,2 x 0,7 | | General use | Stations: AL, CA Tools: AL250-B AP250 |

C250 Cartridges for AL250 Auto-Feed & AP250 Solder Feed Irons








| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|-----------------------------|-------|----------------------|---|
| | C250-405 | Cartridge Bent 1,8 x 0,8 | | General use | Stations: AL, CA Tools: AL250-B AP250 |
| | C250-406 | Cartridge Bent 2,2 x 1 | | General use | Stations: AL, CA Tools: AL250-B AP250 |
| | C250-418 | Cartridge Bent 3,2 x 1,5 | | General use | Stations: AL, CA Tools: AL250-B AP250 |
| | C250-412 | Cartridge Bent 4,8 x 1,5 | | General use | Stations: AL, CA Tools: AL250-B AP250 |
| | C250-407 | Cartridge Chisel 1,2 x 0,7 | | General use | Stations: AL, CA Tools: AL250-B AP250 |
| | C250-408 | Cartridge Chisel 2,2 x 1 S1 | | General use | Stations: AL, CA Tools: AL250-B AP250 |
| | C250-413 | Cartridge Chisel 2,2 x 1 S2 | | General use | Stations: AL, CA Tools: AL250-B AP250 |
| | C250-411 | Cartridge Chisel 4,8 x 1,5 | | General use | Stations: AL, CA Tools: AL250-B AP250 |

C250 Cartridges for AL250 Auto-Feed & AP250 Solder Feed Irons

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|-----------------------|---|--------------------------------|---|
|  | C250-414 | Cartridge Bevel Ø 2,2 |  | Drag soldering Through hole | Stations: AL, CA Tools: AL250-B AP250 |
|  | C250-415 | Cartridge Bevel Ø 3,8 |  | Drag soldering Through hole | Stations: AL, CA Tools: AL250-B AP250 |



C420 Cartridge range
for **HT420 Thermal Tweezers**

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|---------------------------|---|---|--|
| | C420-271 | Cartridge Chip 1,5 |  | SMD resistors SMD capacitors | Control Units: DI, DDE, DME Tool: HT420-A |
| | C420-287 | Cartridge Chip 2 |  | Special | Control Units: DI, DDE, DME Tool: HT420-A |
| | C420-272 | Cartridge Chip 2,6 |  | SMD resistors SMD capacitors | Control Units: DI, DDE, DME Tool: HT420-A |
| | C420-273 | Cartridge Dual in Line 4 |  | Package 1210, 1812 SO, SOT,.. DIP | Control Units: DI, DDE, DME Tool: HT420-A |
| | C420-274 | Cartridge Dual in Line 6 |  | DIP IC | Control Units: DI, DDE, DME Tool: HT420-A |
| | C420-275 | Cartridge Dual in Line 8 |  | DIP IC | Control Units: DI, DDE, DME Tool: HT420-A |
| | C420-276 | Cartridge Dual in Line 10 |  | DIP IC | Control Units: DI, DDE, DME Tool: HT420-A |

C420 Cartridges for **HT420** Thermal Tweezers

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|-----------------------------------|-------|----------------------|--|
| | C420-277 | Cartridge Dual in Line 15 | | DIP IC | Control Units: DI, DDE, DME Tool: HT420-A |
| | C420-278 | Cartridge Dual in Line 20 | | DIP IC | Control Units: DI, DDE, DME Tool: HT420-A |
| | C420-285 | Cartridge Dual in Line 22 | | QFP PLCC | Control Units: DI, DDE, DME Tool: HT420-A |
| | C420-279 | Cartridge QFP 8 | | QFP PLCC | Control Units: DI, DDE, DME Tool: HT420-A |
| | C420-280 | Cartridge QFP 11 | | QFP PLCC | Control Units: DI, DDE, DME Tool: HT420-A |
| | C420-281 | Cartridge Stripper Inf. Ø 3,5 Max | | Wire stripper | Control Units: DI, DDE, DME Tool: HT420-A |
| | C420-282 | Cartridge Stripper Sup. Ø 3,5 Max | | Wire stripper | Control Units: DI, DDE, DME Tool: HT420-A |
| | C420-286 | Cartridge "U" Shape 15,6 x 14,3 | | Special | Control Units: DI, DDE, DME Tool: HT420-A |

C420 Cartridges for **HT420** Thermal Tweezers

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|--------------------|-------|---------------------------------------|--|
| | C420-283 | Cartridge Blade 50 | | Pad cleaning Connector desoldering | Control Units: DI, DDE, DME Tool: HT420-A |



C470 Cartridge range









for T470 HD Handles and HT470 HD Thermal Tweezers

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|-----------------------------|-------|----------------------|--------------------------------|
| | C470-001 | Cartridge Conical Ø 1,7 | | General use | Station: HDE Tools: T470 range |
| | C470-008 | Cartridge Bent Ø 3,5 | | General use | Station: HDE Tools: T470 range |
| | C470-013 | Cartridge Chisel 2 x 0,9 | | General use | Station: HDE Tools: T470 range |
| | C470-036 | Cartridge Chisel 2 x 1 | | General use | Station: HDE Tools: T470 range |
| | C470-014 | Cartridge Chisel 4 x 1,3 S1 | | General use | Station: HDE Tools: T470 range |
| | C470-040 | Cartridge Chisel 4 x 1,3 S2 | | General use | Station: HDE Tools: T470 range |
| | C470-035 | Cartridge Chisel 4 x 2,5 | | General use | Station: HDE Tools: T470 range |









C470 Cartridges for T470 HD Handles and HT470 HD Thermal Tweezers

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|----------------------------|-------|-------------------------|--------------------------------|
| | C470-017 | Cartridge Chisel 5 x 1,2 | | General use | Station: HDE Tools: T470 range |
| | C470-009 | Cartridge Chisel 5,5 x 1,5 | | General use Sheet metal | Station: HDE Tools: T470 range |
| | C470-002 | Cartridge Chisel 6 x 1,5 | | General use Sheet metal | Station: HDE Tools: T470 range |
| | C470-015 | Cartridge Chisel 6 x 1,7 | | General use | Station: HDE Tools: T470 range |
| | C470-004 | Cartridge Chisel 7,5 x 1,5 | | General use Sheet metal | Station: HDE Tools: T470 range |
| | C470-016 | Cartridge Chisel 7,5 x 1,7 | | General use | Station: HDE Tools: T470 range |
| | C470-058 | Cartridge Chisel 8 x 2,5 | | General use Sheet metal | Station: HDE Tools: T470 range |
| | C470-039 | Cartridge Chisel 8,5 x 2,5 | | General use Sheet metal | Station: HDE Tools: T470 range |

C470 Cartridges for **T470** HD Handles and **HT470** HD Thermal Tweezers

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|--------------------------------|---|----------------------------|---|
|  | C470-006 | Cartridge Chisel 10 x 2,5 |  | General use Sheet metal | Station: HDE Tools: T470 range |
|  | C470-007 | Cartridge Chisel 15,5 x 2,5 |  | General use Sheet metal | Station: HDE Tools: T470 range |
|  | C470-021 | Cartridge Chisel 12 x 4 |  | Sheet metal General use | Station: HDE Tools: T470 range |
|  | C470-022 | Cartridge Chisel 28 x 4 |  | Sheet metal | Station: HDE Tools: T470 range |
|  | C470-018 | Cartridge Bent 8,9 x 1,7 |  | General use Sheet metal | Station: HDE Tools: T470 range |
|  | C470-034 | Cartridge Bent 3,5 x 1,5 |  | General use | Station: HDE Tools: T470 range |
|  | C470-019 | Cartridge Bevel Ø 3,5 |  | General use | Station: HDE Tools: T470 range |
|  | C470-003 | Cartridge Bevel Ø 7,5 |  | General use Sheet metal | Station: HDE Tools: T470 range |

C470 Cartridges for **T470** HD Handles and **HT470** HD Thermal Tweezers

| | Ref. | Description | Image | Suggested components | Connectables |
|---|----------|---------------------------------------|---|--|---|
|  | C470-056 | Cartridge Bevel Ø 10 |  | Wide area Shield desoldering Sheet metal | Station: HDE Tools: T470 range |
|  | C470-005 | Cartridge Flat Ø 15 |  | Shield desoldering Metal PCB Sheet metal | Station: HDE Tools: T470 range |
|  | C470-044 | Cartridge Flat 10 x 15 |  | Shield desoldering Metal PCB Sheet metal | Station: HDE Tools: T470 range |
|  | C470-057 | Cartridge Flat 20 x 30 |  | Shield desoldering Metal PCB Sheet metal | Station: HDE Tools: T470 range |
|  | C470-028 | Cartridge Pin / Connector Ø 1,2 |  | Cable Through hole | Station: HDE Tools: T470 range |
|  | C470-031 | Cartridge Pin / Connector Ø 3,2 |  | Cable Through hole | Station: HDE Tools: T470 range |
|  | C470-048 | Cartridge Pin / Connector Ø 3,4 |  | Cable Through hole | Station: HDE Tools: T470 range |
|  | C470-049 | Cartridge Pin / Connector Ø 5,2 |  | Cable Through hole | Station: HDE Tools: T470 range |









C470 Cartridges for T470 HD Handles and HT470 HD Thermal Tweezers

| | Ref. | Description | Image | Suggested components | Connectables |
|--|-----------------|----------------------------------|-------|----------------------|--------------------------------|
| | C470-055 | Cartridge Pin / Connector Ø 4 | | Cable Through hole | Station: HDE Tools: T470 range |
| | C470-033 | Cartridge Pin / Connector Ø 3,65 | | Cable Through hole | Station: HDE Tools: T470 range |
| | C470-030 | Cartridge Pin / Connector Ø 5 | | Cable Through hole | Station: HDE Tools: T470 range |
| | C470-037 | Cartridge Pin / Connector Ø 8 | | Cable Through hole | Station: HDE Tools: T470 range |
| | C470-047 | Cartridge Pin / Connector Ø 14 | | Cable Through hole | Station: HDE Tools: T470 range |
| | C470-052 | Cartridge Pin / Connector R. 8,5 | | Cables connectors | Station: HDE Tools: T470 range |
| | C470-010 | Cartridge Pin / Connector R. 8 | | Cables connectors | Station: HDE Tools: T470 range |
| | C470-029 | Cartridge Pin / Connector R. 31 | | Connectors | Station: HDE Tools: T470 range |




C470 Cartridges for T470 HD Handles and HT470 HD Thermal Tweezers

| | Ref. | Description | Image | Suggested components | Connectables |
|--|-----------------|-----------------------------------|-------|------------------------------------|--------------------------------|
| | C470-041 | Cartridge Pin / Connector Ø 12,5 | | Cable Through hole | Station: HDE Tools: T470 range |
| | C470-042 | Cartridge Pin / Connector Ø 4,8 | | Cable Through hole | Station: HDE Tools: T470 range |
| | C470-012 | Cartridge Pin / Connector R. 6 S1 | | Cables Connectors | Station: HDE Tools: T470 range |
| | C470-038 | Cartridge Pin / Connector R. 6 S2 | | Wide area Cables Connectors | Station: HDE Tools: T470 range |
| | C470-020 | Cartridge Pin Ø 2,4 | | Through hole | Station: HDE Tools: T470 range |
| | C470-045 | Cartridge Pin Ø 3,5 | | Through hole Male connector | Station: HDE Tools: T470 range |
| | C470-011 | Cartridge Hook Ø 4,2 | | Difficult to reach | Station: HDE Tools: T470 range |
| | C470-064 | Cartridge Blade 10 | | Pad cleaning Connector desoldering | Station: HDE Tools: T470 range |

C470 Cartridges for **T470** HD Handles and **HT470** HD Thermal Tweezers

| | Ref. | Description | Image | Suggested components | Connectables |
|---|-----------------|------------------------------|---|---------------------------------------|---|
|  | C470-059 | Cartridge Blade 20 |  | Pad cleaning Connector desoldering | Station: HDE Tools: T470 range |
| | C470-023 | Cartridge Blade 32 |  | Pad cleaning Connector desoldering | Station: HDE Tools: T470 range |
| | C470-051 | Cartridge Blade Split 21 |  | Connectors | Station: HDE Tools: T470 range |
| | C470-025 | Cartridge for Plastics Ø 1,7 |  | Plastics | Station: HDE Tools: T470 range |
| | C470-026 | Cartridge for Plastics Ø 3,5 |  | Plastics | Station: HDE Tools: T470 range |
| | C470-032 | Cartridge for Plastics Ø 9 |  | Plastics | Station: HDE Tools: T470 range |
| | C470-027 | Cartridge Shield 43 x 20 |  | Shield desoldering | Station: HDE Tools: T470 range |
| | C470-043 | Cartridge Groove 1,1 x 10 |  | Wire soldering | Station: HDE Tools: T470 range |

C470 Cartridges for **T470** HD Handles and **HT470** HD Thermal Tweezers

| | Ref. | Description | Image | Suggested components | Connectables |
|--|------------------|---------------------------------|---|---|---|
| | C470-046 | Cartridge Single Flat 7,5 |  | General use Sheet metal | Station: HDE Tools: T470 range |
| | C470-050 | Cartridge Pin / Connector Ø 3,8 |  | Cable Connectors | Station: HDE Tools: T470 range |
| | C470-SP01 | Solder Pot Cartridge 15 x 18 |  | Tinning wires Desoldering Through Hole Multipin components | Station: HDE Tools: T470 range |



C360 Tips range for DS360 Micro Desoldering Iron

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|---------------------------------|-------|--------------------------|--|
| | C360-001 | Micro Desoldering Tip Ø 0,6 | | Through hole Desoldering | Control Units: CV, DI, DDE, DME Tool: DS360-A Modules: MVE / MSE (Pump) |
| | C360-002 | Micro Desoldering Tip Ø 0,8 | | Through hole Desoldering | Control Units: CV, DI, DDE, DME Tool: DS360-A Modules: MVE / MSE (Pump) |
| | C360-003 | Micro Desoldering Tip Ø 1 | | Through hole Desoldering | Control Units: CV, DI, DDE, DME Tool: DS360-A Modules: MVE / MSE (Pump) |
| | C360-004 | Micro Desoldering Tip Ø 1,2 | | Through hole Desoldering | Control Units: CV, DI, DDE, DME Tool: DS360-A Modules: MVE / MSE (Pump) |
| | C360-007 | Micro Desoldering Tip Ø 1,4 | | Through hole Desoldering | Control Units: CV, DI, DDE, DME Tool: DS360-A Modules: MVE / MSE (Pump) |
| | C360-006 | Micro Desoldering Tip Ø 1,5 | | Through hole Desoldering | Control Units: CV, DI, DDE, DME Tool: DS360-A Modules: MVE / MSE (Pump) |
| | C360-011 | Micro Desoldering Tip Ø 0,6 Pad | | Pad desoldering | Control Units: CV, DI, DDE, DME Tool: DS360-A Modules: MVE / MSE (Pump) |

C360 Tips for DS360 Micro Desoldering Iron

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|---------------------------------|-------|----------------------|--|
| | C360-012 | Micro Desoldering Tip Ø 0,8 Pad | | Pad desoldering | Control Units: CV, DI, DDE, DME Tool: DS360-A Modules: MVE / MSE (Pump) |
| | C360-013 | Micro Desoldering Tip Ø 1 Pad | | Pad desoldering | Control Units: CV, DI, DDE, DME Tool: DS360-A Modules: MVE / MSE (Pump) |
| | C360-014 | Micro Desoldering Tip Ø 1,2 Pad | | Pad desoldering | Control Units: CV, DI, DDE, DME Tool: S360-A Modules: MVE / MSE (Pump) |



C560 Tips range for DR560 Desoldering Iron

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|--------------------------|-------|--------------------------|---|
| | C560-001 | Desoldering Tip Ø 0,6 HT | | Through hole Desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |
| | C560-002 | Desoldering Tip Ø 0,8 HT | | Through hole Desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |
| | C560-014 | Desoldering Tip Ø 0,8 | | Through hole Desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |
| | C560-003 | Desoldering Tip Ø 1 | | Through hole Desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |
| | C560-017 | Desoldering Tip Ø 1,1 | | Through hole Desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |
| | C560-004 | Desoldering Tip Ø 1,3 | | Through hole Desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |
| | C560-009 | Desoldering Tip Ø 1,3 | | Through hole Desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |

C560 Tips for DR560 Desoldering Iron

| | Ref. | Description | Image | Suggested components | Connectables |
|--|----------|------------------------------|-------|--------------------------|---|
| | C560-005 | Desoldering Tip Ø 1,5 | | Through hole Desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |
| | C560-006 | Desoldering Tip Ø 1,9 | | Through hole Desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |
| | C560-007 | Desoldering Tip Ø 2,4 | | Through hole Desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |
| | C560-015 | Desoldering Tip Ø 3 | | Through hole Desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |
| | C560-011 | Desoldering Tip Ø 0,6 HT Pad | | Pad desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |
| | C560-012 | Desoldering Tip Ø 0,8 HT Pad | | Pad desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |
| | C560-013 | Desoldering Tip Ø 1 Pad | | Pad desoldering | Control Units: DI, DDE, DME Tool: DR560 Modules: MVE / MSE (Pump) |

Notes

smartTec

smart technology products and solutions

www.smarttec.dk



www.jbctools.com